How to use the R-Link system - HAVS Monitoring

How it works



1. Collect

Unclip any R-Link watch with a Reactec logo 🔐 indicating it is ready for use.



5. Connect

To connect with each tool, press and release the right hand button so that the watch displays an image of a tag. Present the watch over the tool tag until your hear a beep. Tool details will be displayed on the watch screen.



2. Assign

Present a programmed operator card to the R-Link watch.



6. Return

At the end of a shift, return the R-Link watch to a charging station to recharge. Slip the watch down into a bay until it clips in place. A Gateway within 30m collects and transmits data

R-Link watch display





3. Check

If signing out an R-Link watch for HAV monitoring, ensure a yellow hand icon is shown on the top row. If not, notify your supervisor.



4. Protect

Insert the R-Link watch into a strap, pushing one side in first then clipping the remainder into place. Attach the wrist strap snugly to the wrist.

How to assemble an R-Link watch into a strap

A wrist strap is required to secure the R-Link watch to the wrist. Ensure the R-Link watch is fully fitted into the watch strap.



NOTE: The wrist strap is personal and should always be subject to appropriate occupational hygiene procedures regarding cleaning and replacement.

Switch OFF R-Link watch during non-tool use

The R-Link watch can be switched off when moving from a high vibration tool to avoid exposure points being accumulated after use of such a tool. Press and hold the right hand button until the message OFF appears. Release the button then press once more to confirm the R-Link watch is to be switched OFF. The R-link watch will beep to confirm the instruction and show OFF on the screen until another tool is tagged.

R-Link Charger and Gateway



Charger

The charger must be mounted in an indoor location and powered from a mains supply. It is recommended it be positioned where it is convenient for operators to collect their R-Link watches at the beginning and end of shift.

Every charger must be within 30m of a Gateway. The ratio of watches to Gateways should be less than 31.





The 2-Bay Gateway must be powered by a mains supply.

2-Bay Gateway:

It must be connected to the Internet by the internal mobile phone SIM or a local WiFi network if there is a weak mobile signal.



Cleaning Equipment

It is recommended an Isopropanol or similar alcohol based cleaning agent with an alcohol content of at least 70% is used for cleaning. This should be applied with a cloth and with the charger powered down. Use of chemicals not fitting this description may cause damage.



The R-Link watch should be fully charged before being put into storage when not mounted in a powered up charger. It is also recommended to recharge the R-Link watch on a regular basis (monthly) with a 1 hour top-up charge.

-R-Link
