



1. Sign out

Place an ID card against the orange swirl icon on the Docking station to sign out a HAVwear.

2. Collect

Unclip the HAVwear from the bay with the flashing LED light

3. protect

Insert HAVwear into the holder so that the strap is in contact with the wrist. Snugly fit the strap around the wrist (do not remove until returning to a Docking station).

4. Connect

Before using each tool, press & release the HAVwear button once and place the HAVwear over a tool tag until a beep sounds, to "Connect" to the tool. The display will show the last 4 characters of the tool ID to confirm connection.

HAVWEAR user tips

Switch off/on the HAVWEAR during non tool use

- Hold the HAVwear button for 5 seconds until the screen displays "OFF".
- Release and then press the HAVwear button again for 1 second to confirm.
- To switch a HAVwear back on simply connect with a tool before use.

How to assemble and fasten the HAVWEAR to the wrist

A holder and strap are required to secure a HAVwear to the wrist.
NOTE: The wrist strap is personal and should always be subject to appropriate occupational hygiene procedures regarding cleaning and replacement.

Incorrect strap routing and wearing

HAVwear device is exposed to the skin and worn loosely on the wrist.



Correct strap routing and wearing

HAVwear device is behind the strap and worn snugly on the wrist.



HAVwear screen display & alerts

Exposure points
HAV risk exposure points

Latest tool used
Last 4 characters of tool model number

Exposure traffic lights
Circles in coloured bar indicates thresholds reached

Operator initials
First name initial and first three characters of last name

Operator alerts: Beeps and vibrates	Below action value	EAV exceeded Split into 3 equal sections to indicate incremental exposure	ELV exceeded
	2 sec alert	5 sec alert	10 sec alert
		20 sec alert	

HSE guidance on exposure thresholds

- BAV** Try to remain within this threshold
- EAV** Take actions to reduce risk
- ELV** Do not exceed this threshold



The HAVwear should be re-charged fully before being put into storage where not mounted in a powered up docking station. It is also recommended to recharge the unit on a regular basis (monthly) with a 1 hour top up charge.