

How to use RASOR and HAVwear from a Dual Charger (incl SAFE-DISTANCE)

REACTEC

INFORM : PROTECT : DEPLOY



Sign out a HAVwear

1. Press and release the small charger button. Wait until a red LED flashes next to a HAVWEAR to indicate the device to place a valid ID card on top of the HAVWEAR until a beep sounds.
2. Remove the ID card and the HAVWEAR which will display the first name initial and first three letters of the ID card owner's last name.
3. Insert the HAVwear into the holder so only the strap is in contact with the wrist. Snugly fit the strap around the wrist (do not remove until returning to a Docking station).
4. Before using each tool, press & release the HAVwear button once before placing the HAVwear over or on a tool tag until a beep sounds, to "Connect" to the tool. The display will show the first 4 characters of the tool ID to confirm connection.
5. Return to charger at end of shift.



Sign out a RASOR

1. Remove the RASOR from the dual charger and the screen will display the need to assign the RASOR to a user by pressing the button.
2. The screen displays an instruction to place a valid ID card onto the screen area. Once placed remove the ID card when a beep sounds to confirm the RASOR has been assigned.
3. After assignment the screen will display the users first name initial and last name. It will also display the option to select the button to view the main menu.
4. The main menu button controls are displayed at the top of the screen to navigate and select the menu options below.
5. To return a RASOR, place the device onto a dual charger. Press the left button to log out. Do not log out if RASOR is to remain assigned to gather data. RASOR will auto log out 4 hours after being placed onto the Dual Charger.

RASOR Main menu navigation



Main menu options

HAV View personal and/or assigned colleague exposure points.	Noise	Alrts View & confirm personal and/or assigned colleague alerts.	Panic Press both buttons simultaneously for 6 seconds to initiate an alarm.	Chk-in Pre-defined periodic safety check-in.	Sys Check device status.
--	--------------	---	---	--	------------------------------------

HAVWEAR Switch OFF HAV detection during non tool use

- Hold the HAVwear button for 5 seconds until the screen displays "OFF".
- Release and then press the HAVwear button again for 1 second to confirm.
- To switch a HAVwear back on simply connect with a tool before use.

When at a SAFE-DISTANCE, HAVwear screen display & alerts



SAFE-DISTANCE display when colleagues close



HSE guidance on exposure thresholds

BAV Try to remain within this threshold	EAV Take actions to reduce risk	ELV Do not exceed this threshold
---	---	--

The RASOR and HAVwear should be re-charged fully before being put into storage where not mounted in a powered up dual charger. It is also recommended to recharge the unit on a regular basis (monthly) with a 1 hour top up charge.